

SPRING BOLT RELEASE BUTTON ARX 100

NO IMAGE
AVAILABLE

Attributes

- Name: BERETTA USA SPRING BOLT RELEASE BUTTON ARX 100
- Manufacturer: BERETTA USA
- Product no.: 913000549
- Mfr. No.: UD8A0357
- Model: ARX 100
- Weapon type: Beretta
- Delivery weight: 0.005kg
- Shipping height: 25mm
- Shipping width: 102mm
- Shipping length: 152mm

Item details

US export classification: 0A501.x

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for BERETTA USA SPRING BOLT RELEASE BUTTON ARX 100](#)
- [Français: Guide de Sécurité pour le Bouton de Déclenchement de Verrou à Ressort ARX 100](#)

Safety Instruction Guide for BERETTA USA SPRING BOLT RELEASE BUTTON ARX 100

Introduction

Thank you for choosing the BERETTA USA SPRING BOLT RELEASE BUTTON for your ARX 100. This product is designed to enhance the functionality of your firearm while ensuring safety during use. Please read and follow these safety instructions carefully to ensure safe and effective operation.

General Safety Guidelines

- Always treat your firearm as if it is loaded.
- Keep your finger off the trigger until you are ready to shoot.
- Always point the firearm in a safe direction.
- Store firearms and ammunition separately and securely.
- Ensure that the area is clear of people and obstacles before using the firearm.
- Be aware of your surroundings and any potential hazards.
- Do not use the product if it is damaged or malfunctioning.
- Ensure that you are legally allowed to possess and use the firearm and its accessories.

Specific Safety Precautions for Use

- This product is intended for use with the ARX 100 platform only. Do not attempt to use it with other firearms.
- Ensure that the firearm is unloaded before installing or removing the SPRING BOLT RELEASE BUTTON.
- Keep hands and fingers away from moving parts during installation and use.
- Regularly inspect the SPRING BOLT RELEASE BUTTON for wear or damage. Replace if necessary.
- Use appropriate protective gear, such as safety glasses and ear protection, when operating your firearm.
- Be aware that modifications to your firearm may affect its performance and safety. Consult a qualified gunsmith if unsure.

Instructions for Installation and Usage

1. Installation:

- Ensure the firearm is unloaded and pointed in a safe direction.
- Locate the existing bolt release button on your ARX 100.
- Remove the old bolt release button according to the manufacturer's instructions.
- Align the SPRING BOLT RELEASE BUTTON with the mounting point.
- Securely install the SPRING BOLT RELEASE BUTTON, ensuring it is firmly in place.
- Test the installation by pressing the button to ensure it functions correctly.

2. Usage:

- When using the SPRING BOLT RELEASE BUTTON, ensure that your firearm is pointed in a safe direction.
- Press the button to release the bolt as needed during operation.
- Always follow standard firearm safety practices when operating your firearm.

Disposal Instructions

- Dispose of the SPRING BOLT RELEASE BUTTON in accordance with local regulations.
- Do not dispose of the product in regular household waste.

- Contact your local waste management authority for guidance on proper disposal methods.

Contact Information for Further Support

For any inquiries regarding safety or product performance, please contact the manufacturer or your local firearms dealer. Ensure you have the product details ready for reference.

By following these guidelines, you can enhance your shooting experience with the SPRING BOLT RELEASE BUTTON while maintaining safety and compliance with EU regulations. Thank you for prioritizing safety in your firearm usage.

Guide de Sécurité pour le Bouton de Déclenchement de Verrou à Ressort ARX 100

Introduction

Félicitations pour votre achat du Bouton de Déclenchement de Verrou à Ressort ARX 100 de Beretta USA. Ce produit est conçu pour vous offrir une utilisation sécurisée et efficace. Veuillez lire attentivement ce guide de sécurité avant de l'utiliser afin de garantir votre sécurité et celle des autres.

Lignes Directrices Générales de Sécurité

- Assurez-vous que le produit est utilisé uniquement pour son usage prévu.
- Gardez le produit hors de portée des enfants et des personnes vulnérables.
- Ne tentez pas de modifier ou de réparer le produit vous-même.
- Vérifiez régulièrement l'état du produit pour détecter tout signe d'usure ou de dommage.
- En cas de doute sur la sécurité du produit, cessez de l'utiliser immédiatement et contactez un professionnel.

Précautions de Sécurité Spécifiques à l'Utilisation

- Utilisez toujours le bouton de déclenchement de verrou à ressort dans un environnement sûr, loin de toute source de danger.
- Ne forcez pas le bouton si vous rencontrez une résistance. Cela pourrait endommager le mécanisme.
- Ne pointez jamais le produit vers soi ou vers d'autres personnes lors de son utilisation.
- Portez des lunettes de protection si vous utilisez le produit dans un environnement où des éclats ou des débris peuvent être présents.
- Évitez de porter des vêtements amples ou des bijoux qui pourraient se coincer dans le mécanisme.

Instructions pour l'Installation et l'Utilisation

1. Installation :

- Lisez attentivement le manuel d'instructions fourni avec le produit.
- Assurez-vous que la surface d'installation est propre et sèche.
- Fixez le bouton de déclenchement de verrou à ressort selon les instructions de montage.
- Vérifiez que le bouton est bien en place et qu'il fonctionne correctement avant de l'utiliser.

2. Utilisation :

- Pour activer le bouton, appuyez fermement mais doucement pour éviter d'endommager le mécanisme.
- En cas de dysfonctionnement, ne tentez pas de réparer le produit vous-même. Contactez un professionnel.

Instructions de Dépôt

- Ne jetez pas le produit avec les déchets ménagers.
- Renseignez-vous sur les réglementations locales concernant le recyclage des équipements électroniques et des pièces.
- Déposez le produit dans un centre de recyclage agréé ou suivez les instructions fournies par votre municipalité.

Informations de Contact pour un Support Supplémentaire

Pour toute question ou préoccupation concernant la sécurité de votre produit, veuillez consulter le site Web officiel de Beretta USA ou le point de contact de sécurité approprié dans votre pays.

Conclusion

Le respect de ces lignes directrices de sécurité contribuera à garantir une utilisation sûre et efficace de votre Bouton de Déclenchement de Verrou à Ressort ARX 100. Pour votre sécurité et celle des autres, restez vigilant et informé des meilleures pratiques.