

BERETTA SO SERIES REAR SIDE PLATE SCREW

NO IMAGE
AVAILABLE

Attributes

- Name: BERETTA USA BERETTA SO SERIES REAR SIDE PLATE SCREW
- Manufacturer: BERETTA USA
- Product no.: 913500335
- Mfr. No.: C57909
- Weapon type: Beretta
- Delivery weight: 0.045kg
- Shipping height: 3mm
- Shipping width: 89mm
- Shipping length: 152mm

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for BERETTA USA BERETTA SO SERIES REAR SIDE PLATE SCREW](#)
- [Français: Instructions de sécurité pour la vis de plaque latérale arrière de la série SO de BERETTA](#)

Safety Instruction Guide for BERETTA USA

BERETTA SO SERIES REAR SIDE PLATE SCREW

Introduction

Thank you for choosing the BERETTA USA BERETTA SO SERIES REAR SIDE PLATE SCREW. This essential component is designed to ensure the proper functionality and safety of your Beretta SO Series firearm. This guide provides important safety information and instructions to help you use and maintain this product safely.

General Safety Guidelines

- Ensure that all safety precautions are followed when handling firearms.
- Always keep firearms pointed in a safe direction.
- Store firearms and ammunition in a secure location, out of reach of children.
- Regularly inspect your firearm and its components for wear and damage.
- If you suspect any component is damaged or malfunctioning, do not use the firearm and consult a qualified gunsmith.
- Report any unsafe products or accidents to the relevant authorities.
- Check for recall updates on the EU's Safety Gate platform.

Specific Safety Precautions for Use

- Only use the BERETTA SO SERIES REAR SIDE PLATE SCREW with compatible Beretta SO Series firearms.
- Ensure the firearm is unloaded before performing any installation or maintenance.
- Wear appropriate safety gear, including eye protection, when working on your firearm.
- Keep your work area clean and free from distractions while handling firearm components.
- Follow all local laws and regulations regarding firearm maintenance and modifications.

Instructions for Installation and Usage

1. Preparation

- Ensure the firearm is completely unloaded. Remove all ammunition from the vicinity.
- Gather necessary tools, including a screwdriver suitable for the screw type.

2. Installation of the Rear Side Plate Screw

- Locate the rear side plate on your Beretta SO Series firearm.
- Align the screw with the designated hole in the rear side plate.
- Insert the screw and tighten it securely using the appropriate screwdriver. Ensure it is snug but do not overtighten, as this may damage the component.

3. PostInstallation Check

- After installation, visually inspect the rear side plate to ensure it is securely attached.
- Perform a function check of the firearm to ensure everything operates correctly.

4. Maintenance

- Regularly check the tightness of the rear side plate screw during routine firearm maintenance.
- Replace the screw if it shows signs of wear or damage.

Disposal Instructions

- Dispose of any damaged or wornout screws in accordance with local regulations.
- Do not dispose of screws in regular household waste. Check for local recycling programs or hazardous waste disposal options.

Contact Information for Further Support

For any questions or concerns regarding the BERETTA SO SERIES REAR SIDE PLATE SCREW, please consult your local Beretta dealer or authorized service center for assistance.

Instructions de sécurité pour la vis de plaque latérale arrière de la série SO de BERETTA

Introduction

Merci d'avoir choisi la vis de plaque latérale arrière de la série SO de BERETTA. Ce guide vous fournira des instructions de sécurité essentielles pour assurer une utilisation correcte et sécurisée de ce produit. Veuillez lire attentivement toutes les sections avant d'utiliser le produit.

Directives de sécurité générales

- Assurez-vous que le produit est utilisé uniquement pour son but prévu.
- Vérifiez régulièrement l'état de la vis et remplacez-la si elle est endommagée ou usée.
- Conservez le produit hors de portée des enfants.
- Ne modifiez pas la vis ou n'utilisez pas d'accessoires non recommandés par le fabricant.
- En cas de doute sur la sécurité du produit, contactez un professionnel.

Précautions de sécurité spécifiques à l'utilisation

- Utilisez des outils appropriés lors de l'installation pour éviter des blessures.
- Portez des lunettes de protection pour éviter les projections lors de l'installation.
- Ne forcez pas la vis lors de l'installation pour éviter de l'endommager ou d'endommager le produit.
- Ne laissez pas de pièces détachées à proximité d'enfants ou d'animaux domestiques.

Instructions pour l'installation et l'utilisation

1. Préparation:

- Rassemblez tous les outils nécessaires, y compris un tournevis adapté.
- Assurez-vous que la surface de travail est propre et dégagée.

2. Installation:

- Alignez la vis avec le trou de la plaque latérale.
- Insérez la vis à la main pour éviter de la croiser.
- Utilisez le tournevis pour serrer la vis, mais ne la serrez pas trop.

3. Vérification:

- Après l'installation, vérifiez que la vis est bien en place et stable.
- Testez la plaque latérale pour vous assurer qu'elle est correctement fixée.

Instructions d'élimination

- Ne jetez pas le produit dans les ordures ménagères.
- Suivez les réglementations locales pour le recyclage des métaux.
- Si le produit est endommagé, contactez un centre de recyclage approprié.

Informations de contact pour un soutien supplémentaire

Pour toute question ou préoccupation concernant la sécurité de ce produit, veuillez contacter un professionnel qualifié ou consulter le site Web du fabricant pour des informations supplémentaires.

Merci de votre attention et de votre engagement envers la sécurité. En suivant ces instructions, vous contribuerez à garantir une utilisation sûre et efficace de la vis de plaque latérale arrière de la série SO de BERETTA.