

QUAD HUNTER PRO FINNFIRE STOCK RIGHT HAND

NO IMAGE
AVAILABLE

Attributes

- Name: SAKO QUAD HUNTER PRO FINNFIRE STOCK RIGHT HAND
- Manufacturer: SAKO
- Product no.: 913501245
- Mfr. No.: S51868680
- Model: Quad
- Style: Factory Replacement
- Weapon type: Sako

Item details

US export classification: 0A501.y.1

Table of Contents

- [Startpage](#)
- [English: Safety Instruction Guide for SAKO QUAD HUNTER PRO FINNFIRE STOCK RIGHT HAND](#)
- [Français: Guide de Sécurité pour la Crosse SAKO QUAD HUNTER PRO FINNFIRE pour Droitier](#)

Safety Instruction Guide for SAKO QUAD HUNTER PRO FINNFIRE STOCK RIGHT HAND

Introduction

Thank you for choosing the SAKO QUAD HUNTER PRO FINNFIRE STOCK RIGHT HAND. This guide provides essential safety instructions and guidelines to ensure the safe use and maintenance of your stock. Please read all sections carefully to understand how to handle your product safely.

General Safety Guidelines

- Ensure that the stock is compatible with your SAKO QUAD rifle model before use.
- Always handle your firearm and stock with care, treating them as if they are loaded at all times.
- Store your firearm in a secure location, out of reach of children and unauthorized users.
- Regularly inspect your stock for any signs of wear or damage. If you notice any issues, do not use the stock until it has been inspected by a qualified gunsmith.
- Be aware of your surroundings and ensure that you are in a safe environment when handling your firearm.

Specific Safety Precautions for Use

- Always wear appropriate safety gear, including eye and ear protection, when shooting.
- Do not modify or alter the stock in any way, as this may compromise its safety and performance.
- Ensure that the stock is properly attached to the rifle before use. Refer to the installation instructions provided below.
- Do not use the stock with ammunition that exceeds the specifications of your rifle.
- Be cautious when transporting your firearm. Ensure it is unloaded and stored securely during transport.

Instructions for Installation and Usage

Installation

1. **Preparation:** Ensure your rifle is unloaded and pointed in a safe direction.
2. **Remove Old Stock:** If applicable, carefully remove the existing stock from your SAKO QUAD rifle, following the manufacturer's instructions.
3. **Align the Stock:** Position the SAKO QUAD HUNTER PRO FINNFIRE STOCK onto the rifle, aligning it with the mounting points.
4. **Secure the Stock:** Use the appropriate screws and tools to firmly attach the stock to the rifle. Ensure it is tight but do not overtighten, as this may damage the stock.
5. **Check Stability:** Once installed, check for stability by gently shaking the rifle. It should feel secure and not have any excessive movement.

Usage

- Ensure that the stock is clean and free from any obstructions before use.
- Practice proper shooting techniques to maximize the performance of your stock.
- After use, clean the stock according to the manufacturer's recommendations to maintain its condition.

Disposal Instructions

- When disposing of the stock, follow local regulations regarding the disposal of firearm components.
- If the stock is damaged beyond repair, consider recycling materials where possible.
- Do not dispose of the stock in regular household waste.

Contact Information for Further Support

For any inquiries related to safety or product support, please consult your local authorized dealer or visit the official SAKO website for further assistance.

Thank you for your attention to these safety instructions. Your safety and the safety of others depend on your responsible handling and care of the SAKO QUAD HUNTER PRO FINNFIRE STOCK RIGHT HAND.

Guide de Sécurité pour la Crosse SAKO QUAD HUNTER PRO FINNFIRE pour Droitier

Introduction

Merci d'avoir choisi la crosse SAKO QUAD HUNTER PRO FINNFIRE pour droitier. Ce guide a pour but de vous fournir des informations essentielles pour assurer une utilisation sécuritaire de ce produit. Il est important de suivre ces instructions pour éviter tout risque et garantir votre sécurité ainsi que celle des autres.

Directives Générales de Sécurité

- Assurez-vous que le produit est utilisé conformément aux instructions fournies.
- Vérifiez régulièrement l'état de la crosse pour détecter toute usure ou dommage.
- Ne laissez pas le produit à la portée des enfants.
- En cas de doute sur la sécurité du produit, cessez son utilisation immédiatement.
- Consultez les mises à jour de rappel sur la plateforme Safety Gate de l'UE.

Précautions de Sécurité Spécifiques à l'Utilisation

- Ne pas utiliser la crosse si elle présente des signes visibles de dommages.
- Évitez d'utiliser des accessoires non recommandés par le fabricant.
- Ne modifiez pas la crosse d'une manière qui pourrait compromettre sa sécurité ou son intégrité.
- Portez toujours des équipements de protection appropriés lors de l'utilisation de votre carabine.
- Ne jamais pointer la carabine vers soi ou vers d'autres personnes.

Instructions pour l'Installation et l'Utilisation

1. Installation de la Crosse :

- Placez la crosse sur une surface plane et stable.
- Alignez la crosse avec le mécanisme de la carabine SAKO.
- Assurez-vous que la crosse est correctement fixée en suivant les instructions du fabricant.
- Vérifiez que tous les vis et fixations sont bien serrés avant utilisation.

2. Utilisation de la Crosse :

- Tenez fermement la carabine par la crosse.
- Assurez-vous que votre doigt est en dehors de la détente jusqu'à ce que vous soyez prêt à tirer.
- Soyez conscient de votre environnement lorsque vous utilisez la carabine.

3. Entretien :

- Nettoyez la crosse avec un chiffon doux et sec.
- Évitez d'utiliser des produits chimiques agressifs qui pourraient endommager le matériau.
- Inspectez régulièrement la crosse pour détecter des fissures ou des points d'usure.

Instructions de Mise au Rebut

- Ne jetez pas le produit avec les déchets ménagers.
- Suivez les réglementations locales concernant l'élimination des produits en plastique et en métal.
- Si la crosse est endommagée au-delà de son utilisation, contactez un centre de recyclage approprié pour vous en débarrasser.

Informations de Contact pour un Support Supplémentaire

Pour toute question ou préoccupation concernant la sécurité de ce produit, veuillez consulter le site web du fabricant ou contacter un point de vente agréé.

En suivant ces instructions et en respectant les directives de sécurité, vous contribuerez à garantir une expérience d'utilisation sûre et agréable de votre crosse SAKO QUAD HUNTER PRO FINNFIRE pour droitier.