

T3 HUNTER BUTT PLATE SPACER SET

NO IMAGE
AVAILABLE

Attributes

- Name: TIKKA T3 HUNTER BUTT PLATE SPACER SET
- Manufacturer: TIKKA
- Product no.: 913501271
- Mfr. No.: S54065190
- Finish: Black
- Material: Polymer
- Model: T3
- Size: 1/8 in
- Weapon type: Tikka
- Delivery weight: 0.091kg
- Shipping height: 13mm
- Shipping width: 152mm
- Shipping length: 254mm

Table of Contents

- [Startpage](#)
- [English: TIKKA T3 HUNTER BUTT PLATE SPACER SET Safety Instruction Guide](#)
- [Français: Guide de Sécurité pour l'Ensemble d'Entretoises pour Plaque de Couche TIKKA T3 HUNTER](#)

TIKKA T3 HUNTER BUTT PLATE SPACER SET

Safety Instruction Guide

Introduction

Thank you for choosing the TIKKA T3 HUNTER BUTT PLATE SPACER SET. This product is designed to enhance your shooting experience by allowing you to customize the fit of your TIKKA T3 Hunter rifle. To ensure safe and effective use, please read this safety instruction guide carefully.

General Safety Guidelines

- Always follow local laws and regulations regarding the use of firearms and accessories.
- Ensure that the product is used only for its intended purpose.
- Keep the product out of reach of children and unauthorized users.
- Regularly inspect the product for any signs of wear or damage before use.
- In case of any malfunction or if you notice any unusual behavior while using the product, cease use immediately and consult a professional.

Specific Safety Precautions for Use

- Ensure that your rifle is unloaded before installing or adjusting the butt plate spacer set.
- Use only the spacers included in this set; do not attempt to use incompatible parts.
- When adjusting the length of pull, make gradual changes and test the fit before finalizing the adjustment.
- Avoid using excessive force during installation or adjustment to prevent damage to the spacers or the rifle.
- Always wear appropriate eye protection when shooting.

Instructions for Installation and Usage

Installation Steps

1. **Preparation:** Ensure your TIKKA T3 Hunter rifle is unloaded and placed on a stable surface.
2. **Remove Existing Butt Plate:** Unscrew the existing butt plate from the rifle using a suitable screwdriver.
3. **Select Spacer:** Choose the appropriate spacer from the set according to your desired length of pull.
4. **Attach Spacer:** Align the spacer with the butt of the rifle and securely attach it using the provided screws.
5. **Reattach Butt Plate:** Position the butt plate over the spacer and screw it back into place, ensuring it is tightly secured.
6. **Check Fit:** Test the fit of the rifle against your shoulder to ensure comfort and proper alignment.

Usage Tips

- Regularly check the tightness of the screws to ensure the spacers remain securely attached during use.
- Make adjustments as necessary to maintain optimal comfort and shooting performance.

Disposal Instructions

- Dispose of any packaging materials responsibly, following local recycling guidelines.
- If the product is no longer usable, dispose of it in accordance with local regulations for plastic and polymer waste.

Contact Information for Further Support

For any questions or concerns regarding the TIKKA T3 HUNTER BUTT PLATE SPACER SET, please refer to the manufacturer's official website or customer service resources.

By following these safety instructions, you can ensure a safe and enjoyable shooting experience with your TIKKA T3 HUNTER BUTT PLATE SPACER SET. Thank you for your attention to safety.

Guide de Sécurité pour l'Ensemble d'Entretoises pour Plaque de Couche TIKKA T3 HUNTER

Introduction

Merci d'avoir choisi l'Ensemble d'Entretoises pour Plaque de Couche TIKKA T3 HUNTER. Ce produit est conçu pour améliorer le confort et l'ajustement de votre arme à feu. Afin d'assurer une utilisation sécurisée et efficace, veuillez lire attentivement ce guide de sécurité.

Directives Générales de Sécurité

- Assurez-vous que le produit est utilisé uniquement conformément aux instructions fournies.
- Vérifiez régulièrement l'état de l'ensemble d'entretoises pour détecter tout signe d'usure ou de dommage.
- Gardez le produit hors de portée des enfants et des personnes vulnérables.
- Ne modifiez pas le produit de quelque manière que ce soit.
- En cas de doute sur la sécurité ou l'utilisation du produit, consultez un professionnel.

Précautions de Sécurité Spécifiques à l'Utilisation

- Ne jamais utiliser le produit si vous constatez des fissures ou des dommages visibles.
- Assurez-vous que toutes les pièces sont correctement installées avant d'utiliser votre arme.
- Utilisez uniquement des outils appropriés pour l'installation afin d'éviter les blessures.
- Portez des lunettes de protection lors de l'installation pour éviter les blessures aux yeux.
- Ne placez pas d'objets lourds sur le produit, car cela pourrait causer des dommages.

Instructions pour l'Installation et l'Utilisation

1. Préparation

- Rassemblez tous les outils nécessaires : tournevis, clé Allen, etc.
- Assurez-vous que votre arme est déchargée et sécurisée avant de commencer l'installation.

2. Installation des Entretoises

- Retirez la plaque de couche existante de votre TIKKA T3 HUNTER.
- Sélectionnez l'entretoise de taille appropriée (1/8 in) en fonction de vos besoins.
- Alignez l'entretoise avec les points de fixation de la plaque de couche.
- Fixez l'entretoise à l'aide des vis fournies, en veillant à ce qu'elle soit bien serrée.

3. Remontage

- Remettez la plaque de couche en place en vous assurant qu'elle est correctement positionnée.
- Vérifiez que toutes les vis sont bien serrées et que l'ensemble est stable.

4. Utilisation

- Testez l'ajustement de votre arme après l'installation pour vous assurer qu'il est confortable et sécurisé.
- N'hésitez pas à ajuster les entretoises si nécessaire pour un meilleur confort.

Instructions de Mise au Rebut

- Ne jetez pas le produit dans la nature ou dans des lieux non désignés pour les déchets.
- Consultez les réglementations locales concernant l'élimination des plastiques et des matériaux composites.
- Si possible, recyclez le produit en suivant les directives de recyclage de votre région.

Informations de Contact pour un Soutien Supplémentaire

Pour toute question ou préoccupation concernant la sécurité du produit, veuillez consulter le point de contact de l'UE pour des informations supplémentaires. Assurez-vous de signaler tout produit potentiellement dangereux aux autorités compétentes.

Merci de suivre ces instructions pour garantir une utilisation sécurisée et efficace de votre Ensemble d'Entretoises pour Plaque de Couche TIKKA T3 HUNTER. Votre sécurité est notre priorité.